Geek Heat®

Portable Ceramic Heater with Humidifier

Instruction Manual

Model: HA33-08E
Item No.: HH01

READ AND SAVE THESE INSTRUCTIONS

Toll Free:1-844-801-8880
info@homeeasy.net

Table of contents

Important Instructions	2
Operating Instruction	4
Cleaning And Maintenance	6
Troubleshooting	7
Warranty	8

Specification

Product Name	Portable Ceramic Heater with Humidifier
Model	HA33-08E
Item No.	60401
Max Watts	800
Unit Voltage	120V,60Hz
Unit dims	5.2*5.5*9.8 inch

IMPORTANT INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS BEFORE USING THIS HEATER.
WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND PERSONAL INJURY, INCLUDING THE FOLLOWING:

When switching on the appliance for the first time, allow it to run at full power for about two hours to get rid of the unpleasant smell. Make sure that the room in which the appliance is located is well-ventilated during this operation. If the appliance is switched on, the appliance to emit small crackling sounds when you turn it on for the first time.

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front and top of the heater and keep them away from the sides and rear of the heater. Keep the rear grille away from walls or drapes so as not to block the air intake.
3. Close supervision and supervision is necessary when any heater is used near children or invalids and whenever the heater is left operating and unattended.
4. Always unplug heater when not in use.
5. Do not use any heater with a damaged cord or plug or after the heater malfunctions or has been dropped or damaged in any manner. Discard heater or return to an authorized service facility for examination and/or repair.
6. Do not use outdoors.
7. This heater is not intended for use in bathrooms, laundry areas or other similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord so it will not be tripped over. Do not place any heater where cord may be tripped over.
9. To disconnect heater, turn controls to off, then remove plug from outlet.
10. This appliance has a polarized plug (one blade is wider than the other). This plug is intended to fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Do not connect the heater to extension cords, surge protectors, timers, direct breakers, or an outlet with other appliances connected to the same circuit. Failure to follow these instruction, property damage, injury, or even death may result if not adhered to!
11. Connect to properly polarized outlets only.
12. Do not insert or allow foreign objects to enter ventilation or exhaust openings, as this may cause an electric shock or fire, or damage the heater.
13. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

14. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
15. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, injury to persons or property damage.
16. This heater must be plugged into a 120V, 15amp (or more) circuit of its own. Nothing else can be plugged into the same circuit. If ensure if you home meets this specification, consult a certified electrician prior to use. **Risk of fire, overheat, malfunction, property damage, injury, or even death may result if not adhered to!**
17. To prevent overload and blown fuses, be sure that no other appliance is plugged into the same outlet or into another outlet wired into the same circuit.
18. It is normal for the heater’ s plug and cord to feel warm to the touch. A plug or cord that becomes hot to the touch or becomes distorted in shape may be a result of a worn electrical outlet. Worn outlets or receptacles should be replaced prior to further use of the heater. Plugging heater into a worn receptacle may result in overheating of the power cord or fire.
19. Ensure the heater is on a stable, secure surface to eliminate the potential of tipping over.
20. Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet (power strip).
21. Be sure that the plug is fully inserted into appropriate receptacle. Please remember that receptacles also deteriorate due to aging and continuous use: Replace worn or loose receptacles immediately. Signs of looseness evidenced by the plug, Do not use the receptacle and CALL your electrician.
22. Check that neither the appliance nor the power cable has been damaged in any way during transportation.
23. Make sure that no pieces of polystyrene or other packaging material have been left between elements of the appliance. It may be necessary to pass over the appliance with a vacuum cleaner.
24. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
25. Humidifier can only use the tap water. Do not used untreated water form any other source.
26. Ensure the heater has any water on surface and the cover was not tighted, Do not put it back to the machine.

CAUTION: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

SAVE THESE INSTRUCTIONS

Product Components

Be sure to plug into a 120V AC, 60Hz outlet. Check that the plug and the socket fit well, then you can operate the appliance.



Turn the power switch on, the heater will sound a beep voice and power light will be show red.
You can choose different modes by touch button

1. When pressing the button of HEAT 🔥 turns on the fan and PTC,the indicator light of Heat show orange.Pressing again the indicator will be turn off and the PTC will stop working,but the fan will working after 30 seconds.
2. When pressing the button of OSC turns on the motor and the heater will be swing, Pressing again will be turn off the motor.
3. When pressing the button of HUMIDIFIER 💧 turns on the humidifier,The water tank will be spray; please take out the water tank and add the tap water in before you use the humidifier, Please add the water to the “MAX” of the tank,but back there is no water on the surface of the tank and the cover is tight when you put it back ,Pressing again will be turn off the humidifier,



4. The product has dumping protection. If the product is triggered by dumping, the heater will automatically shut off and will not resume operation.
5. Working time:The heater will be turn off after 8 hour before you turn on,the humidifier will be turn off after 5.5 hour before you turn on;

PROTECTION SYSTEMS

OVERHEAT PROTECTION
This heater includes an overheat protection system that shuts the unit off when parts of the heater overheat. If this occurs, turn the heater off, unplug it, and inspect and remove any objects on or adjacent to the heater that may cause high temperatures. Wait 10 to 20 minutes for the unit to cool down then plug it back in and resume the normal operation.

TIP-OVER SWITCH
Your heater is equipped with a tip-over switch, which is designed to automatically shut off the heater if it accidentally tips over or is knocked. When not in the normal upright position, the heater will automatically come on again. This is a safety to avoid possibility of fire should the unit be accidentally tipped over.

POWER INDICATOR LIGHT
This heater is equipped with a power indicator light. The power light will illuminate when the heater is plugged in.

Cleaning And Maintenance

1. Before any cleaning, make sure that:
   a. The heater is turned OFF
   b. Disconnect power supply at source by removing plug from power outlet.
2. Regular cleaning:
   a. Interior dust can often be removed by using a vacuum cleaner with a crevice tool attachment.
   b. Do not use cleaning spray on liquids or other chemicals on the unit
   c. To clean enclosure, use a clean, soft and tightly damp cloth to gently wipe off the dirt from the surface of the unit. Be sure not to wet the heating element and the switches. Allow the unit to dry completely before using it.

CAUTION: DO NOT ALLOW WATER TO RUN INTO THE INTERIOR OF THE HEATER AS THIS COULD CREATE A FIRE OR ELECTRIC SHOCK HAZARD.

STORAGE

1. Perform the cleaning procedures described in “CLEANING AND MAINTENANCE”
2. Wipe all parts to dry.
3. Pack the heater in a plastic bag and store it in a cool, dry place.

TROUBLESHOOTING

If your heater fails to operate, please follow these procedures prior to contacting Customer Service.

Problem	Probable Cause	Solution
Heater will not power on and shuts off unexpectedly	Heater is not plugged into a 120V polarized outlet/receptacle	Ensure unit is in OFF position. Plug in unit and attempt to turn on again.
	The heater was overheat protective feature has turned it off	Turn off the heater,unplug it and wait at least 10 to 20 minutes for the unit to cool down. Plug the heater back in and turn it on again.
Humidifier will not spray	There has no or to little water in the water tank	Take out the water tank and add the tap water in
	The water tank was poor contact with machine	Take out the water tank and put it back again.
	The water was plug up the spary nozzle when first use	Please use the tissue clean the water in the spray nozzle.

PLEASE DO NOT ATTEMPT TO OPEN OR REPAIR THE HEATER YOURSELF, DOING SO COULD VOID THE WARRANTY AND CAUSE DAMAGE OR PERSONAL INJURY.

LIMITED WARRANTY

HOME EASY LTD warrants to the original consumer or purchaser this Humidifier heat (“Product”) is free from defects in material or workmanship for a period of one (1) year from the date of purchase. If any such defect is discovered within the warranty period, HOME EASY LTD, at its discretion, will repair or replace the Product at no cost. This limited warranty is good only to the original purchaser of the product and effective only from the date of purchase.
For warranty or repair service: Call 844-801-8880 and choose the appropriate prompt, or email info@homeeasy.net. Please have your Product’ s model number, your name, address, city, state, zip code and phone number ready.
NO OTHER WARRANTY IS APPLICABLE TO THIS PRODUCT.THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ANY IMPLIED WARRANTY IS REQUIRED BY LAW, IT IS LIMITED IN DURATION TO THE EXPRESS WARRANTY PERIOD ABOVE. NEITHER THE MANUFACTURER NOR ITS U.S.DISTRIBUTOR SHALL BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL OR PUNITIVE DAMAGES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, WITHOUT LIMITATION, LOST REVENUES OR PROFITS, OR ANY OTHER DAMAGE WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE, SOME STATES AND/OR TERRITORIES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU, THE ORIGINAL PURCHASER, SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR TERRITORY TO TERRITORY.

Geek Heat®

Kool Solutions For Life

Home Easy Ltd.
1275 Blackfield Ave
Fortitude, N.S C0A
Canada
1-844-801-8880